



DIRECTIONS FOR THE SPRING TENSION MOUNTED SHADE (inside mount only)
Adjusts from 37 1/2" to 26 1/2" tip to tip.




MEASURE

Measure inside width of window opening (this will become the **overall width of your shade**). We recommend that you use a metal or wood ruler to get the most accurate measurement.




To determine where to trim your shade:
Deduct 2 inches from the **overall width of your shade**
This measurement is your vinyl shade width
Make a mark on the shade indicating where to trim.
Make sure the mark is on the **spring rod side** of the shade vinyl




TRIM

Remove **slat** from **shade hem** (figure A).
Unroll the shade most of the way, but keep the vinyl attached to the shade tube (figure B)
Find the **U-shaped notches** at the hem line (figure C). Start to trim vinyl at that point closest to your measurement mark (figure D)
From here, tear shade slowly by pulling up about 6" of shade at a time until the vinyl is removed from the **adjustable shade tube** (figure E).
Roll shade back up by hand (figure F)
Replace **slat** into **shade hem** (Figure G) and snap off excess **slat** (figure H)




ADJUST

Adjust **shade tube** by pushing the **spring rod end** to meet the end of **shade vinyl**. The **spring rod** will remain extended.





Shorten spring rod by twisting the **spring rod side grip foot** clockwise. Do not over twist the **spring rod**. Leave about 3/4 inch of the **spring rod** extended beyond window opening measurement.



HANG (Use a step ladder if needed to reach the top of the window)

Hold the shade with two hands up near the mounting points on the inside of the window casing. Place the **spring rod side grip foot** into the window casing first. Push in to place the other **grip foot**. Adjust to level.




Increasing spring tension:

While shade is hanging, pull shade down as far as possible without removing vinyl from roller.

Remove shade from window then hand roll vinyl back onto roller.

Re-hang shade. Repeat if necessary.



Decreasing spring tension:

Remove shade from window. Unroll vinyl from shade by hand. Be careful not to unroll vinyl from roller.

Re-hang shade. Repeat if necessary.